

FIG. 1




FIG. 2




FIG. 3




FIG. 4

| | Host Interface | | | | | | | | | |
|-------|------------------|----------------|---------|----------------|----------------|----------|-----------|----------------|----------------|--|
| pin # | RS-232 | USB | Synapse | Wand Emulation | Keyboard Wedge | IBM 468x | Undecoded | RS232 Download | USB Download | |
| 1 | | jumper to 6(1) | SYN_CLK | | | | DBP | | jumper to 6(1) | |
| 2 | +5V | +5V | +5V | +5V | +5V | +5V | +5V | +5V | +5V | |
| 3 | GND | GND | GND | GND | GND | GND | GND | GND | GND | |
| 4 | TXD | | | WAND_DBP | KBD_CLK | IBM_A | ENABLE | TXD | | |
| 5 | RXD | D+ | | WAND_CTS | TERM_DAT | | SOS | | D+ | |
| 6 | RTS | jumper to 1 | SYN_DAT | WAND_RTS | KBD_DAT | IBM_B | TRIG | RXD | jumper to 1 | |
| 7 | CTS | D - | | | TERM_CLK | | DECODE | | D - | |
| 8 | | | | | | | | | Tied to +5V | |
| 9 | Reserved for EAS | | | | | | | | | |
| 10 | | | | | | | | | | |

FIG. 5




FIG. 6




FIG. 7




FIG. 8